

DTC C0201**Diagnostic Instructions**

- Perform the **Diagnostic System Check - Vehicle** prior to using this diagnostic procedure.
- Review **Strategy Based Diagnosis** for an overview of the diagnostic approach.
- **Diagnostic Procedure Instructions** provides an overview of each diagnostic category.

DTC Descriptor**DTC C0201 04****Antilock Brake System (ABS) Enable Relay Contact Circuit****Circuit/System Description**

The solenoid relay, located within the electronic brake control module (EBCM), supplies battery voltage to all of the valve solenoids.

Conditions for Running the DTC

- Ignition voltage is greater than 9.5 volts.
- The solenoid relay is commanded ON.

Conditions for Setting the DTC

One or more of the following conditions exists:

- The EBCM detects an open in the battery positive voltage circuit to the solenoid valve relay.
- The EBCM detects a stuck open solenoid valve relay or an open circuit between the solenoid valve relay and solenoid valves.

Action Taken When the DTC Sets

- The EBCM disables the ABS/dynamic rear proportion (DRP) for the duration of the ignition cycle.
- A DIC message and/or a warning message may be displayed.

Conditions for Clearing the DTC

- The condition for setting the DTC is no longer present.
- The EBCM automatically clears the history DTC when a current DTC is not detected in 100 consecutive drive cycles.

Reference Information**Schematic Reference****Antilock Brake System Schematics****Connector End View Reference****Component Connector End Views****Description and Operation Reference****ABS Description and Operation****Electrical Information Reference**

- **Circuit Testing**
- **Connector Repairs**
- **Testing for Intermittent Conditions and Poor Connections**
- **Wiring Repairs**

Scan Tool Reference**Control Module References for EBCM****Circuit/System Verification**

With scan tool installed ignition ON clear the DTCs, command the ABS solenoids ON and OFF with a scan tool. Monitor the operation of ABS solenoids turn on and off. Also, drive the vehicle in a straight line at a speed greater than 20 km/h (13 mph). If the DTC did not set as a current DTC see appropriate diagnostic aids.

Circuit/System Testing

1. Ignition OFF, disconnect the harness connector at the EBCM.
2. Test for less than 1.0 ohm of resistance from ground circuit terminal 16 and ground.
 - If greater than the specified range, test the ground circuit for an open/high resistance.
3. Test for less than 1.0 ohm of resistance from ground circuit terminal 16 and ground.
 - If greater than the specified range, test the ground circuit for an open/high resistance.
4. Ignition ON, verify that a test lamp illuminates between the B+ circuit terminal 1 and ground.
 - If the test lamp does not illuminate, test the B+ circuit for a short to ground or an open/high resistance.
5. Verify that a test lamp illuminates between the B+ circuit terminal 32 and ground.
 - If the test lamp does not illuminate, test the B+ circuit for a short to ground or an open/high resistance.
6. If all circuits test normal, test or replace the EBCM assembly.

Repair Procedures

Perform the **Diagnostic Repair Verification** after completing the diagnostic procedure.

Control Module References for EBCM replacement, setup, and programming