

2008 Chevrolet HHR LT

SYSTEM WIRING DIAGRAMS

Fig. 54: Starting Circuit

